



LuK Repair Solution for Dry Double clutches

Disassembly and assembly

Audi, SEAT, Škoda, Volkswagen
0AM 7-speed transmission



SCHAEFFLER
REP>XPERT

The content of this brochure is not legally binding and is solely intended for information purposes. Where legally permissible, all liability on the part of Schaeffler Automotive Aftermarket GmbH & Co. KG devolving in connection with this brochure is excluded.

All rights reserved. Any reproduction, distribution, communication, public reproduction or other publication of this brochure in its entirety or in part is not permitted without prior written consent from Schaeffler Automotive Aftermarket GmbH & Co. KG.

Copyright ©
Schaeffler Automotive Aftermarket GmbH & Co. KG
Juni 2014

Contents

	Page
1 Diagnostics of double clutch transmission	4
1.1 General notes on testing the system	4
1.2 Testing for wear	5
1.3 Visual inspection	5
1.4 Noise	5
1.5 Disconnection problems and slipping clutch	5
1.6 Diagnostics	5
1.7 Damage patterns	6
2 Distinguishing features of double clutch systems – 1st and 2nd generations	7
3 Description and scope of the LuK RepSet® 2CT – 1st and 2nd generations	8
4 Description and scope of the LuK special tools	10
4.1 Basic tool kit	11
4.2 Volkswagen tool kit (Audi, SEAT, Škoda, Volkswagen)	12
4.3 Supplementary tool kit	13
5 Disassembly and assembly of the double clutch	14
5.1 Notes on repairs	15
5.2 Brief description of the repair process	15
5.3 Removal of the double clutch	16
5.4 Removal of the engaging system – 1st generation	21
5.5 Installation of the engaging system – 1st generation	23
5.6 Removal of the engaging system – 2nd generation	26
5.7 Installation of the engaging system – 2nd generation	28
5.8 Setting the engaging system – 1st and 2nd generations	31
5.9 Preparation of the transmission input shafts	36
5.10 Installation of the double clutch	37

1 Diagnostics of double clutch transmission

1.1 General notes on testing the system

Before repairing the double clutch, a few key questions must first be clarified with the customer in order to localise the error as much as possible.

Once the vehicle is ready for driving, we recommend carrying out a test drive. The customer should drive in order to demonstrate any possible malfunctions.

Specific questions for the customer:

- What exactly is not working or what is the exact complaint?
- When did the problem begin?
- Did the problem start suddenly or did it develop gradually (slowly)?
- When does the problem occur?
Sporadically, often, always?
- What driving condition is the vehicle in when the problem occurs?
For example, when starting, accelerating, decelerating, when the engine is cold or warm?
- What is the mileage of the vehicle?
- Is the vehicle subjected to extraordinary loads?
E.g. towing a trailer, high load capacity, frequent hill climbs, operated as taxi, fleet car, rental car, driving school?
- What is the driving profile?
Urban vehicle, short journeys, intercity, motorway?
- Have repairs already been carried out on the clutch/transmission system?
If so, at what mileage? What was the cause of that complaint? What repairs were carried out?

General tests on the vehicle

Before starting the repair on the vehicle, the following points should be checked:

- Defect code entries in control unit (engine, transmission, clutch, comfort, CAN-BUS)
- Battery power

Double clutch on the engine side



Double clutch on the transmission side



1.2 Testing for wear

In addition to the general tests, wear testing can be carried out on the double clutch system. This must be performed as follows:

1. The engine must be warm
2. Carry out a test drive in Tiptronic mode
3. When you reach 6th gear, maintain the speed at approximately 1000 - 1500 rpm
4. Then accelerate fully (ATTENTION: No kickdown)
5. Watch the rev counter
6. If a fluctuation in engine speed of up to 200 rpm occurs when accelerating, the wear limit of the double clutch has been reached
7. The wear limit is not reached if the engine speed increases steadily
8. The test must be repeated from step 3 in 7th gear

1.3 Visual inspection

Prior to each repair, the area of the clutch system should be checked for leaks and damage as a matter of course. Damage caused by parts that have broken off or oil leaks due to defective seals or sealing rings must first be rectified before the clutch is replaced. If there is oil on the clutch, replace it.

1.4 Noise

If noise is heard from the double clutch/flywheel area, ensure that the noise is not emanating from surrounding components such as the emission system, heat guard plates, engine suspension damping blocks, auxiliary equipment etc. The radio, air conditioning and ventilation systems should be switched off during the noise investigation. A stethoscope can also be used in the workshop, for example, to locate the source of the noise.

1.5 Disconnection problems and slipping clutch

Before the transmission is removed and the clutch is replaced, a diagnosis should first be carried out with a suitable diagnostic device. If no nonconformity is stored in the memory of the control unit, there is a high probability that the malfunctions are being caused by the mechanical assembly of the double clutch system. An incorrect clearance is one possible cause here. If these defects occur after the repair, the engaging system has been set incorrectly and this must be repeated (see page 31).

1.6 Diagnostics

The transmission and clutch electronics can be diagnosed using a suitable diagnostic device. Prior to each repair, the contents of the error memory should be read and, if possible, retained as a printout. The error memory report provides an initial overview of the system errors and forms the basis for further repair measures. It provides the necessary data for assessing the errors (important when contacting the LuK INA FAG Service Centre or in the event of a warranty claim).

Finally, a basic setting of the clutch system must be carried out with a suitable diagnostic device after any work on the double clutch.

Note:

If you have any questions about diagnosis and repair, please contact our LuK INA FAG Service Centre:
+49 6103 753-333.

1.7 Damage patterns

DMF anti-backlash spring

Problem

- Rattling

Cause


- The retaining lugs on the anti-backlash spring are broken

Remedy

- Replace DMF

Attention:

Broken parts of the anti-backlash spring can also be found in the double clutch. Replacement of the double clutch is therefore recommended!



DMF anti-backlash spring

Problem


- Rattling

Cause

- The preload of the anti-backlash spring is too weak. There must be no visible gap between the anti-backlash spring and the gear tooth of the drive plate. The force of the internal spring must push the anti-backlash spring back into its initial position

Remedy

- Replace DMF




2 Distinguishing features of double clutch systems – 1st and 2nd generations


The first generation dry double clutch transmission system has been used in the OAM 7-speed transmission since 2008. Since then it has been constantly developed in many areas. However, the changes to date have not affected the repair process when replacing the double clutch.

Transmissions built after June 2011 were launched onto the market as the second generation of the dry double clutch transmission system. The main distinguishing features are the change to the structure of the engagement lever and engagement bearing.

The generation that is installed can be identified without disassembling the transmission. To do this, the lower soundproofing of the engine and, on some vehicles, also a cover in the area around the transmission mechatronics must be removed. The double clutch transmission system used in each case can then be identified, either from the version of the engagement lever or via the transmission construction date on the underside of the bell housing.



The construction date can be read off the underside of the transmission. This transmission was produced on 10/07/2012. A 2nd generation double clutch system is installed here.



Cast engagement lever – transmission construction date up to May 2011, 1st generation



Engagement lever made from sheet steel – transmission construction date from June 2011, 2nd generation

3 Description and scope of the LuK RepSet® 2CT – 1st and 2nd generations

1st generation

The LuK RepSet® 2CT (Twin Clutch Technology) includes all the necessary components to replace the double clutch transmission. It is recommended that this system be entirely replaced as a matter of course due to the scope of repair required.

A combination of used parts and new parts from the LuK RepSet® 2CT is not permitted. This will eliminate malfunctions such as those caused by composite installations from the outset.



- | | |
|--|------------------------|
| 1 Double clutch | 7 Snap ring |
| 2 Large engagement lever for clutch K1 including engagement bearing and guiding sleeve | 8 Clip |
| 3 Small engagement lever for clutch K2 including guiding sleeve | 9 Mounting screws |
| 4 Engagement bearing for clutch K2 | 10 Shims for clutch K1 |
| 5 Pilot bearing | 11 Shims for clutch K2 |
| 6 Counterbearing | 12 Plug |

2nd generation

The contents of the LuK RepSet® 2CT are tailored exactly to the spare parts required when replacing the 2nd generation double clutch. It includes the newly redesigned engagement lever, all the necessary shims or graded spherical caps, as well as the one-piece counterbearing.

The remaining contents of the LuK RepSet® are largely identical to those in the 1st generation 2CT. The components of these two systems are not compatible. A combination of used parts and new parts from the LuK RepSet® 2CT is not permitted.



- | | |
|---|-----------------------------|
| 1 Double clutch | 6 Counterbearing |
| 2 Large engagement lever K1 including engagement bearing and guiding sleeve | 7 Plug |
| 3 Small engagement lever K2 including guiding sleeve | 8 Snap ring |
| 4 Engagement bearing K2 | 9 Mounting screws |
| 5 Pilot bearing | 10 Shims K2 |
| | 11 Graded spherical caps K1 |

4 Description and scope of delivery of the LuK special tools

The LuK special tool is essential for the correct disassembly/assembly of the dry double clutch for the OAM transmission. The double clutch must be disconnected during disassembly of the transmission input shaft and fitted again on assembly. In addition, clutches K1 and K2 must be adjusted using washers.

The setting is also checked using the special tool.

For current and future dry LuK double clutch systems, a modular tool system has been developed by Schaeffler Automotive Aftermarket. This allows all modular units as well as the previous LuK special tool to be combined with each other.



Basic tool kit (left) and Volkswagen tool kit (right)

Note:

If you have any questions about the special tools, please call our LuK INA FAG Service Centre on: +49 6103 753-333.

4.1 Basic tool kit

The basic tool kit (part no. 400 0418 10) represents the basis for the modular tool system. It contains those tools that are generally required for all repairs to double clutches.

In conjunction with a vehicle-specific tool kit, both supplement each other to form a complete kit for professional repairs. This is based on all dry double clutch systems currently available from LuK.



- | | |
|---|--|
| 1 Cross beam with spindle and thrust piece | 8 2 plugs for differential holes |
| 2 3 knurled screws | 9 DMF return tool |
| 3 3 M10 threaded pins, 100 mm long | 10 Release key |
| 4 3 M10 threaded pins, 160 mm long | 11 Special open-end wrench |
| 5 Snap ring pliers, angled | 12 DVD with assembly/disassembly instructions and training video |
| 6 Magnet | |
| 7 Transmission support with height adjustment | |

4.2 Volkswagen tool kit (Audi, SEAT, Škoda, Volkswagen)

This vehicle-specific tool kit (part no. 400 0419 10) must be combined with the basic tool kit. It can be used to disassemble, assemble and adjust both first generation (up to transmission construction date May 2011) and second generation (from transmission construction date

June 2011) dry double clutches in vehicles manufactured by Audi, SEAT, Škoda and Volkswagen with a OAM transmission.



- | | |
|---|--|
| 1 Dial gauge with stand | 9 6 plugs |
| 2 Gauge dimension 32.92 mm (1st generation, K2) | 10 3 puller legs |
| 3 Gauge dimension 48.63 mm (1st generation, K1) | 11 Adjustment gauge for gauge dimension |
| 4 Gauge dimension 32.12 mm (2nd generation, K2) | 12 2 lifting hooks |
| 5 Gauge dimension 48.42 mm (2nd generation, K1) | 13 Weight, 3.5 kg |
| 6 3 spring loaded clamps | 14 DVD with assembly/disassembly instructions and training video |
| 7 Removal support sleeve | |
| 8 Installation pressure sleeve | |

4.3 Supplementary tool kit

The previous LuK double clutch special tool (part no. 400 0240 10) can be adapted to the new, modular tool system range with the supplementary tool kit (part no. 400 0420 10).

Together, the contents of the two tool kits correspond to the basic tool kit and the Volkswagen tool kit.



- | | |
|---|---|
| 1 Transmission support with height adjustment | 6 DMF return tool |
| 2 2 plugs for differential holes | 7 Release key |
| 3 Special open-end wrench | 8 DVD with assembly/disassembly instructions and training video |
| 4 Gauge dimension 32.12 mm (2nd generation, K2) | |
| 5 Gauge dimension 48.42 mm (2nd generation, K1) | |

5 Disassembly and assembly of the double clutch

LuK RepSet® 2CT training video on DVD



The "LuK RepSet® 2CT – Audi, SEAT, Škoda and Volkswagen – OAM 7-Speed Transmission" training video demonstrates and explains all of the steps for removing and installing the double clutch using the LuK special tools.

The informative footage and brochures are included in our special tool box as a DVD. The DVD is also available separately on request.

Note:

If you have any questions about the DVD, please call our LuK INA FAG Service Centre on: +49 6103 753-333.

In addition, the latest version of the training video and brochure is always available for downloading from www.RepXpert.com and www.Schaeffler-aftermarket.com.



5.1 Notes on repairs

Valid for:

OAM 7-speed double clutch transmission in Audi, SEAT, Škoda and Volkswagen (first and second generation)

In combination with:

LuK RepSet® 2CT

Using the special tools:

- Part no. 400 0418 10 in conjunction with 400 0419 10
- Part no. 400 0240 10 in conjunction with 400 0420 10

Important information for proper repairs:

- Repairs should only be performed by qualified personnel and with appropriate workshop tools
- Due to the constant technical developments in series production introduced by the vehicle manufacturer, changes in the repair process (e.g. gauge dimensions) or the required special tools may arise
- As a rule, a repair must be carried out using the latest repair instructions and with the relevant special tools

Current data and information on this can be found at:

www.schaeffler-aftermarket.com or www.RepXpert.com

- If transmission oil escapes during the repair, it must be drained fully. The transmission must be refilled with the quantity of oil specified by the manufacturer (1.7 l). If oil is leaking from the mechatronics, it must not be topped up or replaced. In this case, the entire mechatronics unit must be replaced, taking into account the specifications of the vehicle manufacturer
- We recommend that you check the dual mass flywheel (DMF) and replace if necessary when replacing the clutch. Particular attention must be paid to the gearing and the bracing plate (as described in Chapter 1.7) during this process
- As with the repair of a standard clutch, the pilot bearing must be checked and replaced as necessary when replacing the double clutch
- Before installing the double clutch, the transmission input shafts must be cleaned thoroughly and checked for damage. The splines must then be lubricated with a suitable lubricant. The vehicle manufacturer's instructions are to be observed as a priority. If no specifications about the lubricant are made by the vehicle manufacturer, high-melting point greases with

MoS₂ (e.g. Castrol Olista Longtime 2 or 3) that are temperature-resistant and resistant to ageing can be used as alternative lubricants

- It is important to ensure that only the transmission input shafts are lubricated. All other components of the engagement and clutch system must not be greased or oiled
- The bearing seat on the hollow shaft must be moistened with a drop of transmission oil across the entire circumference before the double clutch is pressed on
- After installing the clutch and transmission, the basic setting of the system must be performed using a suitable diagnostic tool
- Generally speaking, each LuK RepSet® 2CT must be installed in its entirety. A combination of used parts and new parts from the LuK RepSet® is not permitted
- Oily and/or dirty transmission parts must be cleaned before using new components. Cleanliness must be ensured throughout the entire repair process

Attention:

The clutch must not be dropped under any circumstances. As a rule, vibrations should be avoided, as they may have a negative impact on the adjuster.

5.2 Brief description of the repair process

- Remove the transmission
- Disconnect the clutch from the transmission input shaft (hollow shaft)
- Remove the old components of the engagement system
- Install the new components of the engagement system
- Position the engagement bearings with shims
- Press the new clutch onto the hollow shaft
- Check the clearance of the clutch discs
- Install the transmission
- Perform a basic setting of the system with a suitable diagnostic system

5.3 Removal of the double clutch

Attention:

Remove the transmission according to the vehicle manufacturer's specifications!

- Disconnect the vent caps from the transmission (1) and mechatronics (2) and fit plugs (KL-0500-607)



Attention:

If transmission oil is leaking from the transmission during the repair, it must be drained fully. The transmission must be refilled with the quantity of oil specified by the manufacturer (1.7 l)!

If oil is leaking from the mechatronics, it must not be topped up or replaced. In this case, the entire mechatronics unit must be replaced taking into account the specifications of the vehicle manufacturer!



- Mount transmission on an assembly device

or

- Place transmission on a workbench and position in a stable horizontal position facing upwards with the transmission support (KL-0500-802) from the basic tool kit



- Remove the snap ring from the upper clutch disc hub (K1) with a screwdriver



- Remove the snap ring and clutch disc hub (K1)



- Remove the snap ring from the hollow shaft with the snap ring pliers (KL-0192-12); this will damage the ring and it must be replaced


Note:

If the snap ring in the groove of the hollow shaft cannot be removed, the clutch must be pressed down slightly using the special tool kit, as shown on page 38.



5.3 Removal of the double clutch

- Position the clutch in the bell housing so that there is sufficient space for locating in the puller legs
- Insert 3 puller legs (KL-0500-6041) on the clutch assembly



- Install in the first leg between the clutch bell housing and clutch and pull upwards; this inserts the centring pin on the bottom of the clutch into the recess on the leg



- Insert the spring-loaded clamp horizontally into the leg
- Withdraw the plunger against the spring force; rotate by 90° and install on the clutch



- The leg is in the desired position
- Repeat the process with the remaining two legs



- Place the support sleeve (KL-0500-6030) on the hollow shaft




- Mount the cross beam (KL-0500-60) on the support sleeve and legs
- Position the spindle so that the legs can be mounted on the cross beam free from tension using the knurled screws



5.3 Removal of the double clutch

- Screw the knurled screws into the legs by hand



- Tighten 3 countersunk-socket head screws on the cross beam



- Remove the clutch from the hollow shaft by turning the spindle



- Remove the clutch assembly with the cross beam



5.4 Removal of the engaging system – 1st generation

- Remove the small engagement bearing (K2) with the shim. Depending on vehicle model year the shim is positioned below or above engagement bearing




- Remove the large clutch engagement bearing (K1) with the shim and engagement lever



5.4 Removal of the engaging system

- Remove both screws from the retaining plate (Torx T30)



- Remove the retaining plate and engagement lever; this retaining plate is different on some of the previous transmission versions



- Remove the counterbearing from the engagement lever



- Thoroughly clean the transmission input shafts
- Check the radial shaft oil seals rings on the transmission input shafts for leaks

Attention:

The bearing seat of the hollow shaft must be cleaned and must be in good condition!

An oxidised or damaged bearing seat will increase the force when pressing on the clutch to an unacceptable level and consequently damage the bearing arrangement of the hollow shaft in the transmission!



5.5 Installation of the engaging system – 1st generation

- Insert a new counterbearing for the engagement lever; it only fits in one position



- Mount a new small engagement lever (for K2) with a guiding sleeve and new retaining plate; the retaining plate sits on the shoulder of the guiding sleeve
- Tighten the new screws to 8 Nm + 90°
- Ensure the engagement lever is positioned correctly on the counterbearing

Attention:

Do not grease or oil components!



5.5 Installation of the engaging system – 1st generation

- Ensure the engagement lever is positioned correctly on the mechatronics actuator



- Insert a new large engagement lever with engagement bearing (for K1)
- Ensure the engagement lever is positioned correctly on the counterbearing

Attention:

Do not grease or oil components!



- Ensure the engagement lever is positioned correctly on the actuator



- Fit the thickest shim (2.8 mm) on the large engagement bearing (for K1)



- Insert the thickest shim (2.8 mm) for the small engagement bearing (for K2)
- Make sure that the lugs sit in the cutouts of the shim



- Insert a small engagement bearing (for K2)
- Make sure that the lugs sit in the cutouts of the engagement bearing



5.6 Removal of the engaging system – 2nd generation

- Remove the small engagement bearing (for K2) with the shim



- Remove the large clutch engagement bearing (for K1) with the graded spherical cap and engagement lever



- Remove both screws (Torx T30) from the guiding sleeve



- Remove the small engagement lever (K2)



- Remove the counterbearing from the small engagement lever (1)
- The counterbearing of the large engagement lever (2) remains in the transmission



- Thoroughly clean the transmission input shafts
- Check the radial shaft oil seals on the transmission input shafts for leaks

Attention:

The bearing seat of the hollow shaft must be cleaned and must be in good condition! An oxidised or damaged bearing seat will increase the force when pressing on the clutch to an unacceptable level and consequently damage the bearing arrangement of the hollow shaft in the transmission!



5.7 Installation of the engaging system – 2nd generation

- Insert the new counterbearing for the small engagement lever



- Mount a new small engagement lever (K2) with a guiding sleeve
- Tighten the new screws (Torx T30) to 8 Nm + 90°

Attention:

Do not grease or oil components!



- Ensure the small engagement lever for K2 is positioned correctly on the counterbearing and on the mechatronics actuator



- Install a large engagement bearing (K1) with the engagement lever



- Ensure the large engagement lever K1 is positioned correctly on the counterbearing and on the mechatronics actuator



- Install the thickest shim for the small engagement bearing; make sure that the lugs of the sleeve are sitting in the cutouts in the disc



5.7 Installation of the engaging system – 2nd generation

- Install the small engagement bearing; make sure that the lugs of the sleeve are sitting in the cutouts in the bearing



- Install the thickest graded spherical cap for the large engagement bearing

Note:

The thickness of the graded spherical cap is measured at the outer edge.



5.8 Setting the engaging system – 1st and 2nd generations

- For the 1st generation engagement system, use the gauge with a dimension of 48.63 mm (KL-0500-6033; Gold) on the large engagement bearing (for K1)
- For the 2nd generation engagement system, use the gauge with a dimension of 48.42 mm (KL-0500-6081; Black) on the large engagement bearing (for K1)



- Place the 3.5 kg weight (KL-0500-6034) on the gauge; this achieves the specified preload



- Check that the adjustment gauge (KL-0500-6035) can be slid into the snap ring groove on the hollow shaft

Attention:

The gauge must not be pushed down.

The gauge can easily be slid into the snap ring groove without the use of force!

- If this is not possible, replace the assembled shim/graded/spherical cap with the next thinnest shim/graded/spherical cap and try again to slide the adjustment gauge into the snap ring groove



5.8 Setting the engaging system – 1st and 2nd generations

- Repeat until the adjustment gauge can be slid into the snap ring groove without using force; if all three sides of the adjustment gauge fit into the snap ring groove, this is the shim/graded spherical cap for the nominal dimension of K1



- Check whether the correct shim/graded spherical cap has been used; using the relevant engagement lever, attempt to push the engagement bearing axially against the adjustment gauge with the gauge dimension mounted

Attention:

The gauge dimension should not move, or should only move slightly (max. 0.1 mm)!



- Shim/graded spherical cap for the nominal dimension needs to be adjusted to match the individual tolerance of clutch K1

Note:

The tolerance value is printed on the engine side of the clutch. It is marked as K1 and is between -0.40 mm and $+0.40$ mm.

- Subtract or add the individual tolerance to the previously determined shim/graded spherical cap according to what is printed



Example 1

Calculated shim/graded spherical cap for nominal size of clutch K1: 1.8 mm

Tolerance value for clutch K1: -0.2 mm

- $1.8 \text{ mm} - 0.2 \text{ mm} = 1.6 \text{ mm}$

The shim/graded spherical cap to be installed for clutch K1 has a thickness of 1.6 mm.

Example 2

Calculated shim/graded spherical cap for nominal size of clutch K1: 2 mm

Tolerance value for clutch K1: +0.4 mm

- $2 \text{ mm} + 0.4 \text{ mm} = 2.4 \text{ mm}$

The shim/graded spherical cap to be installed for clutch K1 has a thickness of 2.4 mm.



- Insert the theoretical shim/graded spherical cap in the large engagement bearing (K1) and make sure that the shim/graded spherical cap is sitting in the designated recess

Note:

The final shim can be glued on with three drops of superglue for the 1st generation engagement system so that it does not slip when the double clutch is assembled.



- For the 1st generation engagement system, use the gauge with a dimension of 32.92 mm (KL-0500-6032; Gold) on the small engagement bearing (for K2)
- For the 2nd generation engagement system, use the gauge with a dimension of 32.12 mm (KL-0500-6082; Black) on the small engagement bearing (for K2)



5.8 Setting the engaging system – 1st and 2nd generations

- Place the 3.5 kg weight (KL-0500-6034) on the gauge; this achieves the specified preload




- Check that the adjustment gauge (KL-0500-6035) can be slid into the snap ring groove on the hollow shaft

Attention:

The gauge must not be pushed down. The gauge can easily be slid into the groove without the use of force!

- If this is not possible, replace the assembled shim with the next thinnest shim and try again to slide the adjustment gauge into the snap ring groove



- Repeat until the adjustment gauge can be slid into the snap ring groove without force; this establishes the appropriate shim for the nominal dimension of clutch K2



- Check whether the correct shim has been used; using the relevant engagement lever, attempt to push the engagement bearing axially against the adjustment gauge with the gauge mounted

Attention:

The gauge should not move, or should only move slightly (max. 0.1 mm)!



- Shim for the nominal dimension to adjust the individual tolerance of clutch K2

Note:

The tolerance value must be read on the engine side of the clutch. It is marked as K2 and is between -0.40 mm and $+0.40$ mm.

- Subtract or add the tolerance of the previously determined shim according to the sign



Example 1

Calculated shim for nominal size of clutch K2: 1.8 mm

Tolerance value for clutch K2: -0.2 mm

- $1.8 \text{ mm} - 0.2 \text{ mm} = 1.6 \text{ mm}$

The shim to be installed for clutch K2 has a thickness of 1.6 mm.

Example 2

Calculated shim for nominal size of clutch K2: 2 mm

Tolerance value for clutch K2: $+0.4$ mm

- $2 \text{ mm} + 0.4 \text{ mm} = 2.4 \text{ mm}$

The shim to be installed for clutch K2 has a thickness of 2.4 mm.



5.8 Setting the engaging system – 1st and 2nd generations

- Insert the theoretical shim, install the engagement bearing (for K2) and make sure that the lugs are sitting in the cutouts of the shim and engagement bearing



5.9 Preparation of the transmission input shafts

- Prepare 2 pea-sized portions (0.2 g each) of lubricant on a piece of cardboard

Note:

Take the vehicle manufacturer's specifications into account when choosing the lubricant. If no information is available, a high-melting point grease with MoS_2 (e.g. Castrol Olista Longtime 2 or 3) that is temperature-resistant and resistant to ageing can be used.



- Apply a portion of lubricant to the splines of the hollow shaft with a brush
- Apply the other portion to the splines of the solid shaft with the brush

Attention:

If too much lubricant is used, this can cause a failure of the double clutch!



5.9 Preparation of the transmission input shafts

- Moisten the bearing seat on the transmission input shaft with a drop of transmission oil across the entire circumference

Attention:

If too much lubricant is used, this can cause a failure of the double clutch!




5.10 Installation of the double clutch

- Place the new clutch assembly on the hollow shaft; the turning it slightly will ensure that the splines of the clutch disc K2 and the hollow shaft engage



- Check that the clutch is sitting properly on the shaft; to do this, measure the distance between the upper edge of the bearing inner ring and the face of the hollow shaft; it must not exceed 8 mm



5.10 Installation of the double clutch

- Place the pressure sleeve (KL-0500-6031) on the bearing inner ring of the clutch package



- Mount 3 threaded adaptors (KL-0500-6021 or KL-0500-6022) with collar nuts on the transmission bell housing

Note:

Adaptors with a long or short thread are used depending on the mounting options on the transmission.

- Position threaded adaptors at an angle of approximately 120° to each other




- Loosen 3 countersunk-socket head screws on the cross beam
- Mount the cross beam (KL-0500-60) on the threaded adaptors with the knurled screws (KL-0500-6020) so that they are free from tension

Note:

The spindle must be centred in relation to the clutch, must be inserted into the pressure sleeve and must move freely.



- Tighten the 3 countersunk-socket head screws on the cross beam



- Press the clutch onto the hollow shaft by turning the spindle at the pressure sleeve; this process is complete as soon as the full snap ring groove can be seen in one of the windows on the pressure sleeve and the force required to turn the spindle increases noticeably

Attention:

The bearing arrangement of the hollow shaft will be damaged if the spindle is turned any further. This will result in damage to the transmission!

Note:

The spindle should be rotated with a torque wrench that is set to the maximum permissible torque of 12 Nm. The force required to turn the spindle must not cause the torque wrench to be triggered! If it is triggered before the clutch has reached its end position, there is an error!



- Mount the snap ring on the hollow shaft with snap ring pliers (KL-0192-12)

Note:


The side of the snap ring on which the opening is smaller faces upwards.

- As a rule, use a new snap ring



5.10 Installation of the double clutch

- Check the clearance of the lower clutch disc (K2)
- Assemble the dial gauge on the clutch bell housing with the stand (ND-0500-606) and the collar nut
- Place the preloaded test probe on the lower clutch disc and set the dial gauge to zero



- Insert both lifting hooks into the clutch disc hub and lift until it stops
- Read off the clearance from the dial gauge

Note:

This measurement is taken in three places, each offset by 120°.



Note:

The clearance (actual clearance of the clutch disc) must be between 0.3 mm and 1.0 mm at all measuring points. The measured values must not deviate from each other by more than 0.3 mm. If the clearance is outside the tolerance value, the adjustment is faulty and must be repeated. The shim may not have been positioned correctly.

- Once the measurement is complete, swivel the dial gauge to the side, but do not remove; the measuring device is required again to measure the clearance of the upper clutch disc



- Install the clutch disc hub for the upper clutch (K1)

Note:

The hub can only be used in one position due to the wider gear tooth.



- Insert the snap ring

Note:

The position of the ring must be centred in relation to the sheet metal tab, i.e. in relation to the large gear tooth.



- Check the clearance of the upper clutch disc (K1); place the preloaded test probe on the hub of the upper clutch disc

Note:

This measurement is taken in three places, each offset by 120°.



5.10 Installation of the double clutch

- Insert both lifting hooks into the clutch disc hub and lift until it stops
- Read off the clearance from the dial gauge



Note:

The clearance (actual clearance of the clutch disc) must be between 0.3 mm and 1.0 mm at all measuring points. The measured values must not deviate from each other by more than 0.3 mm. If the clearance is outside the tolerance value, the adjustment is faulty and must be repeated. The shim may not have been positioned correctly.



- Put the transmission in the installation position



- Reinstall the transmission according to the vehicle manufacturer's specifications
- Remove the plugs from both vent connections and attach the caps

Attention:

It must be possible to bring the engine and transmission together far enough for the engine and transmission mounting faces to make full contact. Only then should the components be bolted together. Failure to observe this instruction may result in damage to the double clutch!



Attention:

If transmission oil escapes during the repair, it must be drained fully. The transmission must be refilled with the quantity of oil specified by the manufacturer (1.7 l). The existing oil cannot be topped up!

If oil is leaking from the mechatronics, it must not be topped up or replaced. In this case, the entire mechatronics unit must be replaced taking into account the specifications of the vehicle manufacturer!

- Finally, a basic setting of the clutch system must be carried out with a suitable diagnostic tool



