alleuroparts

AST Specials June 2019



AST5189 - Hub Nut Socket - Ford Transit (2014-)

AST5189 - A castellated socket for removal and installation of Rear Axle Hub Nuts on Ford Transit 2014-.

- Chrome Molybdenum Impact Quality Socket
- · Central boss ensures correct installation of the nut on
- · Enables quick and accurate removal and installation of the hub nut
 - Equivalent to Ford OEM Tool Reference: 205-1007



AST4494C Oil Pressure Test Kit

Quality Pressure Gauge 0-7 bar / 0-100 psi Long Reach Hose - 1 metre with quick coupler system 90° Elbow for ease of access Range of 10 Adaptors

Covers Opel-Vauxhall engines with M12x1.75 threaded Oil **Pressure Test Connection**

This quality compression tester comprises:

- · AST4494-1 Oil Pressure Test Gauge & Hose Assembly
- AST4494-2 Elbow Adaptor
 AST3241-1 M10 x 1.0 Adaptor
- AST3241-2 M12 x 1.5 Adaptor AST3241-3 M14 x 1.5 Adaptor
- AST3241-4 M16 x 1.5 Adaptor AST3241-5 M18 x 1.5 Adaptor
- · AST3241-6 1/8" BSPT Adaptor
- AST3241-7 1/8" NPT Adaptor



AST5220 (Chain) Engine Setting / Locking Kit - covers engine setting/timing chain removal and installation proce- BMW - FORD - PSA - VAG dures on N13, N18 and EP6 1.6L four-cylinder petrol engines installed in a number of BMW, Mini, Citröen and Peugeot models. BMW 1.6 N13 - 114i (F20/21)(11-) - 116i (F20/21)(11-) - Audi - A1, A3, A4, A5, A6, Q3, Q5, TT BMW - 1 Series I/II, 2 118i (F20/21)(11-) 316i (F30/31)(12-) - 320i (F30/31)(12-) Citroën Series, 3 Series, 4 Series, 5 Series, X1, X3, Z4Ford - C-MAX, 1.6 EP6 - C5 III - DS4 - DS5 Mini 1.6 N18 - Clubman (R55) (07-15) - Countryman (R60) (10-17) - Coupe (R58) (11-15) Mini 15) Peugeot 1.6 EP6 - 208 - 308 / 308 CC - RCZ

AST5219- (Chain) Engine Support Bracket

AST5219 provides a safe and secure method of supporting the engine until the engine mount has been reinstalled.

- Typical applications include N12, N14, N16, N18 petrol engines fitted in MINI models
 - Securely holds engine block in position
 - Prevents the engine from slipping or dropping



AST6150 - Drain Plug Removal / Installation Tool Set -

Typical Applications:

Focus, Galaxy, Kuga, Mondeo, S-Max, Edge, Transit, Tourneo PSA - C4, C5, DS4, DS5, Jumpy, 308, 508, 3008, 5008 Seat (R56/57) (06-15) - Paceman (R61) (13-17) - Roadster (R59) (12- - Leon, Toledo, Alhambra Skoda - Ibiza, Octavia, Rapid, Superb, Yeti VW - Beetle, Caddy, Golf, Jetta, Passat, Scirocco, Sharan, Tiquan, Touran

AST6150 Set comprises:

- AST6151 Drain Plug set of 3 pc for PSA / Ford
 - · AST6152 Drain Plug set of 3 pc for Ford
 - AST6153 Drain Plug set of 3 pc for BMW
- · AST6154 Drain Plug set of 3 pc for VW Group